



Invista Têxtil

PEÇAS E ACESSÓRIOS

Peças e acessórios para máquinas

Toyota Air Jet



vendas@invistatextil.com.br
lucas@invistatextil.com.br





















(19)99354 - 9099























(19) 3457 - 1419



















Rua do diamante, 82 - São Fernando - Santa Barbara D'Oeste - SP - CEP - 13454 - 250



Cnpj: 21.958.986/0001-87 - Delutex Comercio de Acessórios Têxteis LTDA.

TOYOTA JAT 500		
ELETRICAL PRODUCTS		
<i>MAIN SOLENOID VALVE TOYOTA JAT500</i>		
		
TOYO-0021	TOYO-0022	TOYO-0023
MAIN SOLENOID VALVE TOYOTA JAT 500	COIL FOR MAIN VALVE TOYOTA JAT500	SPRING FOR VALVE OMNI/DELTA/PAT/TOYOTA
		
TOYO-0024	TOYO-0025	TOYO-0214
PISTON	BASE FOR SOLENOID VALVE	BOLT
		
TOYO-0215	TOYO-0216	TOYO-0217
SEAL RING	RUBBER CUSHION BLOCKING	SPRING HOLDER
<i>RELAY SOLENOID VALVE TOYOTA JAT500</i>		
		
TOYO-0026	TOYO-0027	TOYO-0218
RELAY SOLENOID VALVES	BASE RELAY VALVE JAT500	BOLT
		
TOYO-0219	TOYO-0220	TOYO-0221
LID	COIL	ARMATURE
		
TOYO-0222	TOYO-0223	TOYO-0224
SPRING	SEAL RING	SPACER




















		
TOYO-0225 PISTON		
WEFT STORAGE PIN JAT500/600		
		
TOYO-0074 WEFT STORAGE PIN	TOYO-0075 COIL JAT500/600	TOYO-0076 CAP JAT500/600
		
TOYO-0077 CYLINDER JAT500/600	TOYO-0078 PIN JAT500/600	TOYO-0079 SPRING JAT500/600
		
TOYO-0080 SLEEVE JAT500/600/610 15X12	TOYO-0081 RING JAT500/600	TOYO-0082 RUBBER RING JAT500/600
		
TOYO-0083 SLEEVE JAT500/600 10X5	TOYO-0252 NUT	TOYO-0253 UPPER LID
		
TOYO-0254 COIL		
SENSOR & DISPLAY FOR TOYOTA 500		
		
TOYO-0104 DISPLAY JAT500	TOYO-0113 MEMBRANE JAT500	TOYO-0180 LOAD CELL JAT500
TOYOTA JAT 600		
ELETRICAL PRODUCTS		
MAIN SOLENOID VALVE TOYOTA 600		
		
TOYO-0038 MAIN SOLENOID VALVE JAT600	TOYO-0039 SOLENOID	TOYO-0040 BASE FOR MAIN VALVE JAT600

		
TOYO-0041 SPRING	TOYO-0042 PISTON TSUD./TOYT.	TOYO-0043 WIRING FOR PISTON TOYO-0042
		
TOYO-0044 SEAL RING FOR PISTON	TOYO-0045 CYLINDER TSUD./TOYT.	TOYO-0046 SEAL RING D=13.5mm
		
TOYO-0226 BOLT	TOYO-0227 LID	
RELAY SOLENOID VALVE TOYOTA 600		
		
TOYO-0028 RELAY SOLENOID VALVE	TOYO-0029 COIL JAT600	TOYO-0030 SPRING
		
TOYO-0031 PISTON TSUD./TOYT.	TOYO-0032 RING FOR PISTON TOYO-0031	TOYO-0033 SHOCK ABSORBER RING
		
TOYO-0034 SEAL RING FOR PISTON	TOYO-0035 CYLINDER TSUD./TOYT.	TOYO-0036 SEAL RING D=13.5mm
		
TOYO-0037 BASE FOR RELAY VALVE JAT 600	TOYO-0228 BOLT	TOYO-0229 LID
SENSOR & DISPLAY FOR TOYOTA 600/610		
		
TOYO-0288 PRINT-BOARD FEELER	TOYO-0098 CHECK VALVE CONNECTOR 4 BAR	TOYO-0099 SWITCH CARD LH JAT600/610/710


		
TOYO-0100	TOYO-0101	TOYO-0102
SWITCH CARD RH JAT600/710/610	PRINT CARD FOR FEELER JAT600/610/710	POWER SUPPLYING BOX DCPS2
		
TOYO-0103	TOYO-0105	TOYO-0106
POWER SUPPLY BOX DCPS4 24V	LARGE DISPLAY JAT600/610 1 CABLE ASTC-FW	LARGE DISPLAY JAT600/610 2 CABLE RSTS
		
TOYO-0107	TOYO-0108	TOYO-0109
LARGE DISPLAY JAT600/610 2 CABLE SSTT	LARGE TOUCH PANEL JAT600/610 259X170	SMALL DISPLAY JAT600/610 2 CABLE RSTS
		
TOYO-0110	TOYO-0114	TOYO-0115
SMALL DISPLAY JAT600/610 2 CABLE SSTT	KEY MASK TOY .600	OIL LEVELING SENSOR STAUBLI DOBBY
		
TOYO-0116	TOYO-0117	TOYO-0118
STEPPING MOTOR JAT610/710	OPTICAL FIBER CABLE FOR TOYOTA L=5M	OPTIC CABLE JAT600/710 L=6M
		
TOYO-0119	TOYO-0123	TOYO-0124
OPTICAL FIBER CABLE FOR TOYOTA L=7M	WEFT SENSOR WF JAT610/600 L=3.2M	WEFT SENSOR WWF JAT610/600 L=3.2M

























		
TOYO-0128 COUNT SENSOR RHS JAT600/610/710	TOYO-0129 COUNT SENSOR LHS JAT600/610/710	TOYO-0130 SENSOR OIL LEVEL STAUBLI DOBBY
		
TOYO-0181 LOAD CELL JAT 600/610	TOYO-0178 DETECTOR RH FOR WARP STOP BAR JAT600/610	TOYO-0179 DETECTOR LH FOR WARP STOP BAR JAT600/610
TOYOTA JAT 610		
ELETRICAL PRODUCTS		
<i>MAIN/RELAY SOLENOID VALVE TOYOTA 610</i>		
		
TOYO-0047 RELAY SOLENOID VALVE JAT610	TOYO-0048 MAIN/RELAY SOLENOID VALVE JAT610	TOYO-0049 COIL
		
TOYO-0050 CAP	TOYO-0051 SPRING HOLDER	TOYO-0052 SPRING
		
TOYO-0053 PISTON	TOYO-0054 SHOCK ABSORBER RING	TOYO-0055 BASE



















		
TOYO-0230 BOLT	TOYO-0231 LOOP SHELL	TOYO-0232 SEAL RING
		
TOYO-0233 LOWER LID	TOYO-0234 SPACER	
WEFT STORAGE PIN JAT610		
		
TOYO-0065 WEFT STORAGE PIN JAT610	TOYO-0066 COIL	TOYO-0067 CAP
		
TOYO-0068 CYLINDER JAT610	TOYO-0069 PIN JAT610	TOYO-0070 SPRING JAT610
		
TOYO-0071 RUBBER RING JAT610	TOYO-0072 RING JAT610	TOYO-0073 SLEEVE JAT610
		
TOYO-0255 BOLT	TOYO-0256 CONNTCTING BOARD	TOYO-0257 LOOP SHELL
		
TOYO-0258 GUIDE BOARD	TOYO-0259 DISHING SPRING	






















TOYOTA JAT 710		
ELETRICAL PRODUCTS		
MAIN SOLENOID VALVE TOYOTA 710		
		
TOYO-0235	TOYO-0236	TOYO-0237
MAIN SOLENOID VALVE TOYOTA 710	UPPER NUT	SPACER
		
TOYO-0238 COIL	TOYO-0239 LOWER NUT	TOYO-0240 MOTOR
		
TOYO-0241 ARMATURE	TOYO-0242 SPRING	TOYO-0243 PISTON
		
TOYO-0244 SEAL RING	TOYO-0245 BASE	TOYO-0246 CONNECTING BOARD
		
TOYO-0247 BASE		
RELAY SOLENOID VALVE TOYOTA 710		
		
TOYO-0056	TOYO-0057	TOYO-0058
RELAY SOLENOID VALVE JAT710 NEW TYPE	COIL JAT710	SEAL RING
		
TOYO-0059	TOYO-0060	TOYO-0061
PISTON JAT710 WTH OUT HOLE NEW TYPE	CYLINDER JAT710 NEW TYPE	SPRING JAT710 NEW TYPE

		
TOYO-0062	TOYO-0063	TOYO-0064
PISTON JAT710 WITH HOLE OLD TYPE	CYLINDER JAT710 OLD TYPE	SPRING JAT710 OLD TYPE
		
TOYO-0248	TOYO-0249	TOYO-0250
UPPER NUT	SPACER	LOWER NUT
		
TOYO-0251		
BASE		
WEFT STORAGE PIN JAT710		
		
TOYO-0084	TOYO-0260	TOYO-0261
WEFT STORAGE PIN JAT710	BOLT	CONNECTING BOARD
		
TOYO-0085	TOYO-0086	TOYO-0087
COIL JAT710	CAP JAT710	PIN JAT710
		
TOYO-0088	TOYO-0089	TOYO-0090
CYLINDER JAT710	SPRING JAT710	BUSH JAT710
		
TOYO-0091	TOYO-0092	TOYO-0093
SLEEVE 8.1/10X17.2 JAT710	SLEEVE 4/8X12 JAT710	WASHER JAT710
		
TOYO-0094	TOYO-0095	TOYO-0096
STUD JAT710	RING JAT710	RING JAT710

		
TOYO-0097 RING JAT710	TOYO-0262 GUIDE BOARD	TOYO-0263 SPRING AND SPRING HOLDER
SENSOR & DISPLAY FOR TOYOTA 710		
		
TOYO-0111 DISPLAY JAT710	TOYO-0112 TOUCH PANEL JAT710 8PINS	TOYO-0120 WEFT SENSOR WWF JAT710 L=4.5M
		
TOYO-0121 WEFT SENSOR WF JAT710 L=4.5M	TOYO-0122 WEFT SENSOR JAT710 WF/WWF NEW MODEL	TOYO-0125 WEFT SENSOR JAT710 WF/WWF L=2.7M NEW MODEL
		
TOYO-0126 NEW WEFT SENSOR JAT710 WWF L=4.2M RED	TOYO-0127 NEW WEFT SENSOR JAT710 WF L=4.2M GREEN	TOYO-0131 DETECTOR
TOYOTA JAT 810		
ELETRICAL PRODUCTS		
ELECTRONIC PARTS & DISPLAY FOR TOYOTA 810		
		
TOYO-0264 PRINT BOARD FOR WARP STOP BOX JAT810	TOYO-0265 WARP STOP BOX JAT810	TOYO-0266 WARP STOP BOX WITH SCREW JAT810
		
TOYO-0267 WARP STOP BOX WITH HOLDER & CABLE JAT810	TOYO-0268 CABLE, WARP STOP BOX JAT810	TOYO-0269 DISPLAY & TOUCH COMPLETE JAT810
		
TOYO-0270 ABS MOTOR JAT810	TOYO-0271 SWITCH NKK	TOYO-0272 COVER NKK





















		
TOYO-0273 BOARD JAT810	TOYO-0274 ELEC CUTTER MOTOR JAT810	TOYO-0275 ASSY ELEC CUTTER JAT810
		
TOYO-0276 CONTACTOR TORX173	TOYO-0277 CONTACTOR TOTX173	TOYO-0278 LENO MOTOR JAT810
		
TOYO-0279 CONTACTOR	TOYO-0280 CONTACTOR	TOYO-0281 CONTACTOR
		
TOYO-0282 CONTACTOR	TOYO-0283 CONTACTOR	TOYO-0284 CONTACTOR
		
TOYO-0285 CONTACTOR MAGNETIC PAK-	TOYO-0286 CONTACTOR MAGNETIC PAK-	TOYO-0287 PRINT BOARD FEELER
GENERAL SPARE PARTS		
MAIN NOZZLES AND SUB NOZZLES FOR TOYOTA		
		
TOYO-0001 MAIN NOZZLE TOYT. 1C	TOYO-0002 MAIN NOZZLE TOYT. 2C D=2.0	TOYO-0003 MAIN NOZZLE TOYT. 2C
		
TOYO-0004 MAIN NOZZLE TOYT. 4C	TOYO-0005 MAIN NOZZLE TOYT. 6C D=2.0	TOYO-0006 MAIN NOZZLE TUBE L=215MM TOYT.
		
TOYO-0007 MAIN NOZZLE TUBE L=234.5	TOYO-0008 MAIN NOZZLE TUBE L=287	TOYO-0009 THREAD GUIDE D=1.5 TOYT.












		
TOYO-0010	TOYO-0011	TOYO-0012
THREAD GUIDE D=2.0 TOYT.	THREAD GUIDE D=2.5 TOYT.	STRETCHING NOZZLE TOYT.
		
TOYO-0013	TOYO-0014	TOYO-0015
STRETCHING NOZZLE TOYT.	STRETCHING NOZZLE TOYT.	RELAY NOZZLE TOYT. 19H
		
TOYO-0016	TOYO-0017	TOYO-0018
RELAY NOZZLE TOYT. 1H M8	RELAY NOZZLE TUBE TOYT. 1H OFF CENTER	RELAY NOZZLE TUBE TOYT. 1H OFF CENTER
		
TOYO-0019	TOYO-0020	
RELAY NOZZLE TUBE TOYT. 1H CENTER	RELAY NOZZLE TOYT. 19H	
LENO DEVICE FOR TOYOTA		
		
TOYO-0132		
SELVEDGE BOBBIN REWINDER		
		
TOYO-0133	TOYO-0134	TOYO-0135
LENO GEAR JAT500/600/610 LH Z=68	LENO GEAR JAT500/600/610 RH Z=72	LENO GEAR JAT710 LH Z=68
		
TOYO-0136	TOYO-0137	TOYO-0138
LENO GEAR JAT710 RH Z=72	BOBBIN HOLDER RH WITH BOBBIN JAT500/600	BOBBIN HOLDER RH 2 SPRINGS JAT500/600

		
TOYO-0139 BOBBIN HOLDER LH WITH BOBBIN JAT500/600	TOYO-0140 BOBBIN HOLDER LH 2 SPRINGS JAT500/600	TOYO-0141 BOBBIN HOLDER RH 1 SPRINGS WITH BOBBIN JAT500/600
		
TOYO-0142 BOBBIN HOLDER RH 1 SPRINGS JAT500/600	TOYO-0143 BOBBIN HOLDER LH 1 SPRINGS WITH BOBBIN JAT500/600	TOYO-0144 BOBBIN HOLDER LH 1 SPRINGS JAT500/600
		
TOYO-0145 BOBBIN JAT610/710	TOYO-0146 BUSH FOR BOBBIN TOYO-0145	TOYO-0147 BOBBIN INTEGRATED TYPE JAT610/710
		
TOYO-0148 BOBBIN JAT500/600	TOYO-0149 BUSH FOR BOBBIN TOYO-0148	TOYO-0150 PIN FOR LENO BOBBIN PIC./SMT/TOYT.
		
TOYO-0151 STOPPER	TOYO-0152 SPRING	TOYO-0153 YARN GUIDE
		
TOYO-0154 STEEL PIN	TOYO-0155 BOBBIN HOLDER RH JAT710	TOYO-0156 BOBBIN HOLDER LH JAT710
		
TOYO-0157 SPACER	TOYO-0158 TENSION ARM	TOYO-0159 YARN GUIDE

		
TOYO-0160 STOPPER	TOYO-0161 STOPPER PIN	TOYO-0162 BUSH
BLADES FOR TOYOTA		
		
TOYO-0163 TUCK-IN SCISSOR JAT710	TOYO-0164 WEFT FIXED BLADE JAT600/610/710	TOYO-0165 WEFT MOVABLE BLADE JAT600/610/710
		
TOYO-0166 WEFT FIXED BLADE (LONG TYPE) JAT600/610/710	TOYO-0167 WEFT MOVABLE BLADE (LONG TYPE) JAT600/610/710	TOYO-0168 SELVEDGE FIXED BLADE LH JAT610/710
		
TOYO-0169 SELVEDGE MOVABLE BLADE JAT610/710	TOYO-0170 BUSH FOR BLADE	TOYO-0171 MOVABLE BLADE FOR SELV. JAT610/710/L5200
		
TOYO-0172 RING TOYOTA JAT	TOYO-0173 CUTTER LEVER LH	TOYO-0174 BLADE SUPTOYT. JAT610
		
SX-000024 CUTTER SHAFT FOR JAT600 M3	SX-000031 CUTTER SHAFT FOR TOYOTA M3 LONG TYPE	
CLUTCH BRAKE FOR TOYOTA		
		
TOYO-0175 COMPLETE CLUTCH BRAKE TOYOTA 610	TOYO-0176 MAGNET TOYOTA 610	TOYO-0177 SPRING PLATE TOYOTA 610

		
TOYO-0289	TOYO-0290	TOYO-0291
COMPLETE CLUTCH BRAKE TOYOTA 500/600	COIL FOR TOYOTA 500/600	DISC FOR TOYOTA 500/600
		
TOYO-0292	TOYO-0293	TOYO-0294
COMPLETE CLUTCH BRAKE TOYOTA 710	DISC FOR TOYOTA 710	COIL FOR TOYOTA 710
OTHER PARTS FOR TOYOTA		
		
TOYO-0184	TOYO-0185	TOYO-0186
AIR PRESSURE METER -0.1 TO 1MPa SMC TOYT.	SPRING HOLDER JAT610 T=12.3MM	CAM LEVER ROLLERS JAT600
		
TOYO-0187	TOYO-0188	TOYO-0189
DRIVE GEAR Z=40	DRIVE GEAR Z=21	IMMEDIATE GEAR Z=34
		
TOYO-0190	TOYO-0191	TOYO-0192
CONNECTOR D12	AIR FILTER 32X40X40	AIR FILTER 30X36X51
		
TOYO-0193	TOYO-0194	TOYO-0195
AIR FILTER 33X41X46	REGULATOR FOR RELAY NOZZLE	OPTIC CABLE L=9M JAT600/610/710
		
TOYO-0196	TOYO-0197	TOYO-0198
SPROCKET CHAIN L=1.2M	TENSION SPRING	AIR PIPE LOCKER

		
TOYO-0199 TENSION ARM	TOYO-0200 NUT	TOYO-0201 EASING SHAFT
		
TOYO-0202 COMPLETE BRACKET- EASING	TOYO-0203 COMPLETE BRACKET- EASING	TOYO-0204 BRACKET EASING LH
		
TOYO-0205 BRACKET EASING RH	TOYO-0206 LENO SHAFT LH	TOYO-0207 LENO SHAFT RH
		
TOYO-0208 BRACKET,LENO SELVEDGE STAY LH	TOYO-0209 BRACKET,LENO SELVEDGE STAY RH	TOYO-0210 ROD END BEARING RBT12E204
		
TOYO-0211 HOUSING EASING BRACKET	TOYO-0212 YARN TENSIONER(SPRING 0.5MM)	TOYO-0213 YARN TENSIONER (SPRING 0,6MM)
		
SX-000001 BUSH 40X45X30MM	SX-000005 LEVER FOR TEMPLE RH TOYOTA D=8.85	SX-000007 NUT FOR LENO BOBBIN HOLDER TOYOTA 710
		
SX-000011 TEMPLE RING TOYOTA 1.2MM	SX-J1415-10020-0A PLATE FOR TEMPLE TOYOTA	SX-000025 SCREW FOR FIXED BLADE TOYOTA M2X5

		
SX-000026	SX-J1415-13010-00	SX-000035
SCREW FOR FIXED BLADE TOYOTA M3X4	SPECIAL BOLT JAT710	PLASTIC HOLDER FOR WEFT SENSOR TOYOTA
		
SX-000048	SX-000049	SX-000050
NOSE OF TEMPLE TOYOTA	LEVER FOR TEMPLE RH TOYOTA D=8.85	LEVER FOR TEMPLE LH TOYOTA D=8.85
		
SX-000052	SX-000070	SX-000072
PISTON FOR SUB SOLENOID VAVLE JAT600 OLD MODEL	AIR DISTRIBUTOR BLOCK 4 POSITIONS FOR TOYOTA 610	BEAM SHAFT BUSH
		
SX-000084	SX-73311-40001	
AIR DISTRIBUTOR BLOCK 6 POSITIONS FOR TOYOTA 610	BUSH 48x40x40	